

掘削機の適用範囲 (BK-10 II 型～BK-15 II 型)

単位(mm)

		軸 部 径																					
		1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	
拡 底 部 径	1000	1.00																					
	1100	1.00	1.00																				
	1200	1.21	1.00	1.00		BK-10 II																	
	1300	1.44	1.19	1.00	1.00																		
	1400	1.69	1.40	1.17	1.00	1.00		BK-12 II															
	1500	1.96	1.62	1.36	1.16	1.00	1.00																
	1600	2.25	1.86	1.56	1.33	1.15	1.00	1.00															
	1700	2.56	2.12	1.78	1.51	1.31	1.14	1.00	1.00				BK-15 II										
	1800	2.89	2.39	2.01	1.71	1.47	1.28	1.13	1.00	1.00													
	1900	3.24	2.68	2.25	1.92	1.65	1.44	1.27	1.12	1.00	1.00												
	1950	3.42	2.83	2.38	2.03	1.75	1.52	1.34	1.18	1.06	1.00												
	2000	3.61	2.98	2.51	2.14	1.84	1.60	1.41	1.25	1.11	1.00	1.00											
	2100	4.00	3.31	2.78	2.37	2.04	1.78	1.56	1.38	1.23	1.11	1.00	1.00										
	2200		3.64	3.06	2.61	2.25	1.96	1.72	1.53	1.36	1.22	1.10	1.00	1.00									
	2300		4.00	3.36	2.86	2.47	2.15	1.89	1.67	1.49	1.34	1.21	1.10	1.00									
	2400			3.67	3.13	2.70	2.35	2.07	1.83	1.63	1.47	1.32	1.20	1.09	1.00	1.00							
	2500			4.00	3.41	2.94	2.56	2.25	1.99	1.78	1.60	1.44	1.31	1.19	1.09	1.00	1.00						
	2600				3.70	3.19	2.78	2.44	2.16	1.93	1.73	1.56	1.42	1.29	1.18	1.09	1.00	1.00					
	2700				4.00	3.45	3.01	2.64	2.34	2.09	1.87	1.69	1.53	1.40	1.28	1.17	1.08	1.00	1.00				
	2800					3.72	3.24	2.85	2.52	2.25	2.02	1.82	1.65	1.51	1.38	1.27	1.17	1.08	1.00	1.00			
	2900					4.00	3.48	3.06	2.71	2.42	2.17	1.96	1.78	1.62	1.48	1.36	1.25	1.16	1.08	1.00	1.00		
	3000						3.74	3.29	2.91	2.60	2.33	2.10	1.91	1.74	1.59	1.46	1.35	1.24	1.15	1.07	1.00	1.00	
	3100						4.00	3.52	3.12	2.78	2.49	2.25	2.04	1.86	1.71	1.56	1.44	1.33	1.23	1.15	1.07	1.00	
	3200							3.75	3.33	2.97	2.66	2.40	2.18	1.99	1.82	1.67	1.54	1.42	1.32	1.23	1.14	1.07	
	3300							4.00	3.54	3.16	2.84	2.56	2.32	2.12	1.94	1.78	1.64	1.51	1.40	1.31	1.22	1.14	
	3400								3.77	3.36	3.02	2.72	2.47	2.25	2.06	1.89	1.74	1.61	1.49	1.39	1.29	1.21	
	3500								4.00	3.57	3.20	2.89	2.62	2.39	2.19	2.01	1.85	1.71	1.59	1.47	1.37	1.28	
	3600									3.78	3.39	3.07	2.78	2.53	2.32	2.13	1.96	1.81	1.68	1.56	1.46	1.36	
	3700									4.00	3.59	3.24	2.94	2.68	2.45	2.25	2.07	1.92	1.78	1.65	1.54	1.44	
	3800										3.79	3.42	3.10	2.83	2.59	2.38	2.19	2.03	1.88	1.75	1.63	1.52	
3900										4.00	3.61	3.27	2.98	2.73	2.51	2.31	2.14	1.98	1.84	1.72	1.60		
4000											3.80	3.45	3.14	2.88	2.64	2.43	2.25	2.09	1.94	1.81	1.69		
4100											4.00	3.63	3.31	3.02	2.78	2.56	2.37	2.19	2.04	1.90	1.78		
4200															3.18	2.92	2.69	2.49	2.31	2.14	2.00	1.87	
4300															3.33	3.06	2.82	2.61	2.42	2.25	2.10	1.96	
4400															3.50	3.21	2.96	2.74	2.54	2.36	2.20	2.05	
4500															3.66	3.36	3.10	2.86	2.66	2.47	2.30	2.15	
4600															3.83	3.52	3.24	3.00	2.78	2.58	2.41	2.25	
4700															4.00	3.67	3.39	3.13	2.90	2.70	2.52	2.35	

 : 施工範囲
 : 拡底バケット(BK-10 II 型～BK-15 II 型)適用範囲

表中の数値は確定率を示す(確定率=有効底面積÷軸部断面積)